


Hướng dẫn cấu hình internet modem TP-Link TD-W8951ND

I. Hình ảnh modem

Hình dáng và các tín hiệu đèn (lưu ý các đèn trên modem không ghi tên)



Hình dáng modem:



II. Hướng dẫn cấu hình:

Mở trình duyệt web, nhập vào địa chỉ modem mặc định <http://192.168.1.1>

Đăng nhập bằng user/pass mặc định : admin/admin.

Chọn Interface Setup → Internet và cấu hình các thông số như hình dưới.

Bấm Save để lưu cấu hình, hoàn tất.

Interface

Quick Start

Interface Setup

Advanced Setup

Access Management

Maintenance

Status

Help

Internet

LAN

Wireless

ATM VC

Virtual Circuit : PVC0 PVCs Summary

VPI : 0 (range: 0~255)

VCI : 33 (range: 1~65535)

QoS

ATM QoS : UBR

PCR : 0 cells/second

SCR : 0 cells/second

MBS : 0 cells

Encapsulation

ISP : Dynamic IP Address

Static IP Address

PPPoA/PPPoE

Bridge Mode

PPPoE/PPPoA

Servicename : Internet

Username : hndsl-inf4

Password :

Encapsulation : PPPoE LLC

Bridge Interface : Activated Deactivated

Username và password từ nhà cung cấp

Connection Setting

Connection : Always On (Recommended)

Connect On-Demand (Close if idle for 0 minutes)

Connect Manually

TCP MSS Option : TCP MSS(default:1400) 1400 bytes

IP Address

Get IP Address : Static Dynamic

Static IP Address : 0.0.0.0

IP Subnet Mask : 0.0.0.0

Gateway : 0.0.0.0

NAT : Enable

Default Route : Yes No

TCP MTU Option : TCP MTU(default:1480) 1480 bytes

Dynamic Route : RIP2-B

Direction : Both

Multicast : Disabled

SAVE